


# Nipple Dome Jack Type

## Instruction manual


### ■ Parts and name



### ■ For safety use


Please read this instruction manual for safety use before use this product. Please follow to this instruction manual for care and the maintenance. Please keep this instruction manual carefully to be able to look at it anytime.

### Attachment × 2




### Magnet for charge

### Magnet-type USB cable




### ■ How to use


1. Turn a wheel to the left and adjust the height of the attachment. We highly recommend using lotion at contact zone for first time of use.



2. Turn a wheel to the right and fix the main body. Turn a wheel gently and slowly. Otherwise, it may cause of pain.




3. Push button, and, you can enjoy ten different kinds of rotary speed and ten different kinds of rotary patterns.



### ■ How to charge

To start charge, connect a magnet-type USB cable to a charge port PC or a power supply adapter.

※Power supply adaptor is not included.



### ■ Maintenance

- The main body, Please wipe off a dirt of the main body with cloth.
- The attachment is washable when remove from the main body. Please wipe off moisture with dry cloth immediately after washing.  
※The main body and the wireless remote controller is NOT waterproof.
- For charge, please use the attached magnet-type USB cable.

### ■ For safety use

Please follow the security precaution. Otherwise, it may cause of injury and the accident.

- Please do not leave this product in the place getting a high temperature, cool and warm, high humidity, the direct rays of the sun. It causes a change of color or malfunction.
- Please use the water-soluble lotion and massage oil gel.
- Please do NOT remodel, dismantle nor repair the product by own.
- This product is for nipple use only. Please do NOT use for others.
- Please use only an exclusive attachment for the product.
- Please stop use the product immediately, and go to the doctor when you feel the abnormality of the body
- This product is joke goods. Therefore, we cannot take any responsibility for any damage, the accident and any request from a third party by using this product.
- Do NOT place the plug of the product except this product in 2 hole Jack.
- It may cause malfunction when liquids such as a lotion or the water are in 2 hole Jack inside.

### ■ Operation

#### button

ON: Push two seconds  
OFF: Push one time

#### button

rotary speed becomes fast  
(all ten phases)

#### button


Rotary speed becomes fastest while pushing

#### button

Rotary speed becomes slow  
(all ten phases)

#### button

Rotary pattern changes  
(all ten different kinds)



### ■ Specification

Product name	Nipple Dome Jack Type	Weight	282g
Seller	SSI Japan Co., Ltd.	Charge method	Magnet-type USB cable
Distributor	SSI Japan Co., Ltd.	Charge pond	lithium battery 3.7V
Country of manufacture	China	Charge time	2.5h
The main body size	W68×D68×H112mm	Continuation operation time	1.5h
Controller dimensions	W45×D23×H60mm	Accessories	Attachment x 2 Magnet-type USB cable Manual